



The WZ 4 status indicator is intended for optical repetition of the signalling alarming state of the detector or a group of detectors in the fire alarm systems. It can be added to the detector or a group of detectors. The indicator is applied when installed detector is invisible or there is limited access to a room supervised by detectors, for example, it is installed in spaces above ceiling, in cable passages, technical rooms, hotel rooms, etc.

FEATURES OF STATUS INDICATOR WZ 4

- > additional visual signalling
- > small dimensions
- > 4 visual signalling LEDs
- > power intake <4 [mA]</p>

DIMENSIONS [mm]





TECHNICAL DATA

STATUS INDI	CATOR WZ 4
24 [VDC] ± 25%	
0 [mA]	
<0,5 [mA]	
44x23 [mm]	
18 [g]	
WHITE	BLACK
FSS001	FSS041
	24 [VDC 0 [r <0,5 44x23 18 WHITE